



TUFRIGHT DECKING BOARD INSTALLATIONS GUIDE

Specifications	mm
CENTRE TO CENTRE JOIST (SPACING RESIDENTIAL ONLY)	MAX 450mm
MINIMUM BUTT JOIN GAP	6mm
MINIMUM PERIMETER GAP TO STRUCTURES/DWELLING	6mm
MINIMUM GAP BETWEEN BOARDS SIDE BY SIDE	CLIPS
MINIMUM BUTT JOIN GAP TO EDGE BOARD	6mm
MINIMUM SIDE GAP TO EDGE BOARD	6mm
MAXIMUM OVERHANG OF BOARD SHOULD NOT EXCEED	25 mm
MINIMUM GROUND CLEARANCE WITH FRAME	300 mm
MINIMUM GROUND CLEARANCE ON CONCRETE	25mm



PIC 1

1. Measure and mark a line 6/10mm away from your wall/structure (this distance is important to allow for expansion from the house due to weather changes)
2. Screw in the Starter Clips 6/10mm from the wall/structure



PIC 2

3. Lay the first board (starter board) onto the deck – fitting it firmly into the starter clips, use a rubber mallet if necessary



PIC 3

4. Install joiner clips, slide the two bottom sides of the clips in under the starter board, making sure it is firmly in place.

5. Screw the clips in place into the joist.

(DOUBLE JOIST AND 2 CLIPS EACH SIDE IS REQUIRED FOR BUTT JOIN SEE PIC 3 AND 4)



PIC 4

6. Fit the next board onto the other side of the joiner clips, over the screwed part, making sure it is firmly in place. The clips should barely show once the board is properly in place.

7. Repeat steps 4-6 until deck is filled

TUFRIGHT PTY LTD

31A PRODUCTION DRIVE, CAMPBELLFIELD VIC 3061

PHONE: 03 9357 7525

EMAIL: INFO@TUFRIGHT.COM.AU

WWW.TUFRIGHT.COM.AU